

## OIL DISPENSING VALVE FOR PUMP INSTALLATION



Part No  
24516

## TECHNICAL DATA

### OIL DISPENSING VALVE FOR PUMP INSTALLATION

The valve is mounted direct on the pump outlet. To be used for filling of measures and cans. Note Pump not included, ordered separately.

#### TECHNICAL DATA

Part No	24516
Connection	3/4" (M) BSP
H.S. Code	84818081