



## GENERAL

## EN

The lever operated pump that is included in the following kits:

Grease: 21499 21505 21501 21016 21017

Oil: 11713 11714 11715 11710 11711 11712

Can be set to two modes: GREASE or OIL. It's important that you choose the correct lever setting before using the equipment. Failure to do so could damage the equipment. The equipment is not designed to handle any back pressure, this can damage the equipment. If you notice the pump is hard to operate, you should stop using the pump and troubleshoot why it is hard to operate. Some reasons could include:

- Cold operating temperature, meaning the grease or oil is too thick
- Clogged quick coupler

## General operating advice:

The pump produces approximately 20gr per stroke, which means that you as the user need to take care not to pump too quickly. Slow up- and down strokes means that the feeder plate in the bottom of the tube has time to "grab" the grease. If you are pumping too fast, you run the risk of introducing air into the system, and also breaking the piston rod inside the pump if you use too much force.

## ALLMÄNT

## SE

Handdriven pump som ingår i följande kits:

Fett: 21499 21505 21501 21016 21017

Olja: 11713 11714 11715 11710 11711 11712

Kan ställas in i två lägen: FETT eller OLJA. Det är viktigt att du väljer rätt läge genom att flytta sprinten innan du börjar använda utrustningen. Om detta inte görs kan utrustningen skadas. Utrustningen är inte gjord för att användas med mottryck, detta kan skada utrustningen. Om du märker att pumpen går tungt, sluta då att använda pumpen och undersök varför den går tungt. Några anledningar kan vara:

- Kalla temperaturer, vilket innebär att fettet eller oljan är för tjock
- Igensatt snabbkoppling

## Allmänna användningstips:

Pumpen levererar ca 20gr per slag, vilket innebär att du som användare bör tänka på att inte pumpa för fort. Långsamma tag innebär att matarbrickan i nederdelen av pumpröret hinner med att leverera fett. Om man pumpar för snabbt finns risken att man bara pumpar in luft i systemet och att kolvstången kan knäckas om man tar i för hårt.



Part No. / Art. Nr. / Réf.:

**21499, 21505, 21501, 21016, 21017**

**11713, 11714, 11715, 11710, 11711, 11712**