



Mounting instructions:

- 1) **Attach the Air Connection Kit 22587 to the pump. See Pos. 1.**
- 2) **Attach the Gauge 2326013 on the pump. Lock in position with lock nut. See Pos. 2.**
- 3) **Attach the Silencer 2326260 on the pump. See Pos. 3.**
- 4) **Connect the Suction Hose Kit 22588 to the pump. See Pos. 4.**
- 5) **Mount the Bung Adapter 2085147 on the container. See Pos. 5. Pump Adapter fits all containers with 2" thread.**
- 6) **Lubricate the O-ring on the pump with oil and push the Pump into the bung adapter and check that the connection is tight. See Pos. 6.**
- 7) **Before connecting the unit to the air line, check that the Air Valve is closed. Open the Air Valve slowly until the desired suction capacity has been reached.**

Warning!

If the Air Valve is opened when air pressure is connected, you risk to shrink the container! Always adjust the airflow into the pump according to the container and the flow desired.

The pump will stop automatically when the container is full. Empty the container and put back the pump in the adapter in order to start it again.